



**CMMI DEV /2<sup>SM</sup>**  
Exp. 2018-06-12 / Appraisal #24559



# ENERMETER

*Seeing in first*

## who we are

## a successful history



## Who we are

ENERMETER is a technological based company working in the development of innovative solutions on METERING and COMPUTER VISION

- ❑ Started in 2001.
- ❑ Based in Braga, north of Portugal.
- ❑ It offers highly trained professionals with large experience, aiming to answer to any challenge.
- ❑ Total number of collaborators: 26
  - ❑ 23 PhD/MSc/BSc, multidisciplinary group

## Who we are

### COMPUTER VISION DIVISION



Industrial Imaging



ENERMETER  
**MEDICAL IMAGING**



**COMPUTER VISION**  
ACADEMY

### METERING DIVISION

ENERMETER develops and commercializes systems and services for metering, control and management of energy and fluids.



NOT THE FOCUS OF  
OUR PRESENTATION



## Who we are

### COMPUTER VISION DIVISION

ENERMETER creates and develops systems based on image processing and analysis techniques that can be used in inspection of raw-material, components and processes.



ENERMETER  
MEDICAL IMAGING



COMPUTER VISION  
ACADEMY

### Industrial Imaging

ENERMETER's automatic inspection systems put together hardware and software (developed by ENERMETER team) based on the state-of-the-art artificial vision technology.

These automatic inspection systems, designed specifically for each customer, can be implemented in any production line point, saving time and space on the customer side



ENERMETER  
Seeing in first



CMMI DEV / 2<sup>SM</sup>  
Exp. 2018-06-12 / Appraisal #24559



ON.2

O NOVO NORTE  
PROGRAMA OPERACIONAL  
REGIONAL DO NORTE



UNIÃO EUROPEIA  
Fundo Europeu de Desenvolvimento Regional


# Who we are

## COMPUTER VISION DIVISION

ENERMETER creates and develops solutions based on image processing and analysis and artificial intelligence algorithms that can be used in helping diagnosis.



**ENERMETER  
MEDICAL IMAGING**



**COMPUTER VISION  
ACADEMY**

## Medical Imaging

ENERMETER has been developing several projects in medical imaging, such as:

- computerized system for classification of micro-calcifications present in mammography;
- system for Diagnostic and monitoring of Diabetic Retinopathy;
- and
- analysis of musculoskeletal ultrasound image.

## Who we are

### COMPUTER VISION DIVISION

The Academy's mission is to generate smart investment opportunities, particularly in research and innovation in the field of computer vision.



ENERMETER  
MEDICAL IMAGING



COMPUTER VISION  
ACADEMY

Academic skills

Synergies between the ACADEMIC scientific knowledge and the COMPANIES' technical knowledge.

CVA aims to promote sustainable growth of the computer vision area through new players capable of responding to increasingly demanding challenges, creating a solid bridge between the university and the enterprises.

# Who we are

**COMPUTER VISION  
ACADEMY**



Horas	Dia 1	Dia 2	Dia 3	Dia 4	Dia 5
08H30					
09H00					
09H30	CV	CV	CV	CV	CV
10H00					
10H30	Intervalo	Intervalo	Intervalo	Intervalo	Intervalo
11H00					
11H30					
12H00	CV	CV	CV	CV	CV
12H30					
13H00					
13H30	Almoço	Almoço	Almoço	Almoço	Almoço
14H00	Abertura Oficial				
14H30		CEI Apresentação - Casos - Debate			
15H00	BOSCH Apresentação - Casos - Debate		STRONGSTEP Gestão de Requisitos - Casos - Debate		
15H30		Intervalo			
16H00				Intervalo	Intervalo
16H30					
17H00	Intervalo		Atividade Social e Jantar		
17H30	INFAIMON SW			ENERMETER Apresentação - Casos	ENERMETER Apresentação - Casos
18H00	INFAIMON HW				Encerramento

## Who knows us

As a result of ENERMETER's work, capacity and innovative character, the company has increasingly assumed itself as a global leader in the development of innovative solutions in metering and artificial vision.



SAKTHI PORTUGAL, S. A.



## ❑ Computer Vision - Some Projects

- ❑ ESOBASIS - ENERMETER System Of BAckStitch InSpection



- ❑ ESOTIREINSP - ENERMETER System Of Tire Marks Inspection



- ❑ ESOVYM – ENERMETER System Of VineYard Monitoring



- ❑ MICABCAD - Microcalcification Computer-Aided Detection

A handwritten signature in black ink that reads "Dr. Campos Costa".



# ENERMETER

*Seeing in first*

## ESOBASIS

ENERMETER System Of BAckStitch  
InSpection

**faurecia**

## ❑ A system for Backstitch Inspection

### ❑ Colour Defects in Backstitch of Headboard Car Seats

#### ❑ Problem

- ❑ Wrong Colours
- ❑ Tinny Colour Differences
- ❑ Tinny Gray Differences




## ❑ Computer vision architecture

### ❑ Industrial Computer

- ❑ 2 High Resolution Cameras
- ❑ Diffuse illumination

One for each side of  
the headboard car  
seat



## ❑ Computer vision architecture

### ❑ Industrial Computer

### ❑ 2 High Resolution Cameras


❑ Spatial: 2452 X 2056

❑ Depth: 16 bits


### ❑ Diffuse illumination

- Increase the range of tons from 256 to 65536
  - Higher sensibility to minor variations
- From the 16 bits given by the camera remove the 2 less significant
  - Noisy bits
  - 14 bits depth – 16384 tons values per channel

# Inspection Algorithm



# ESOBASIS



## ❑ The winner strategy

- ❑ High resolution cameras
- ❑ High depth of the pixel
- ❑ Color signature based on 10 images of different shutter values
- ❑ Bayesian classifier



# ENERMETER

*Seeing in first*

## ESOTIREINSP

ENERMETER System Of Tire Marks  
Inspection



- Two types of marks:

- Sidewall marks
- Tread Stripes



## ESOTIREINSP – SIDEWALL MARKS



- ❑ A system for mark detection and measuring in tires
  - ❑ Tires needs to be marked according to specific radius and angular position, to define the critical points of the tire. This insures better performance on the road and also less wear/waste when the tire is correctly mounted in the rim.
  - ❑ Human classification/measuring is highly subjective and time consuming
    - ❑ The precision required makes human classification/measuring almost impossible
    - ❑ We most quantify the angle and radial position of the marks


# Sidewall Markings

DENOMINATION	TECHNOLOGY	GEOMETRY	COLOR	VISUAL	REMAKRS
Dot D10 robust	LTA	OD 10mm	Red	●	POMS-spec!
	LTA	OD 10mm	White	●	POMS-spec!
	LTA	OD 10mm	Yellow	●	POMS-spec!
Donut D12 Robust	LTA	OD 12,5mm	Red	○	POMS-spec!
Dot D14 Non-permanent	LTA	OD 14mm	Orange-red	●	POMS-spec!
RHHP-Label (spec. color)	RHHP	35x17mm	Magenta		Color-spec: GM Korea!
	RHHP	35x17mm	Yellow		Color spec: Nissan NA
Force Correction	Ink-Jet	Height 12mm	White	BCD	Width 0,5mm
Conicity-Letter	Ink-Jet	Height 12mm	White	ZN	Letters chosen based on Conicity-Grade: NN, N, P or PP
Conicity Stripes on Tread	Airbrush	Width 6-15mm (readable from a distance of 3m under normal light conditions)	Sorting: DUAL >> White	N:   P:	Applied on tread. 2x, 180° on circumference. Length: 2/3 or tread width.
		Width: 6-15mm (readable from a distance of 3m under normal light conditions)	Sorting: QUAD - narrow limit: green - upper limit: red	Negative:   Positive:    --- Negative:   Positive:	NN – N – P – PP   - I - II -

## Tread Stripes




# Inspection System in the Line




## Acquisition System

### Inspection Station – Areas of Inspection



## Acquisition System - Sidewall

### Bottom Camera



Linear Camera

Two led bars  
illuminators

## Acquisition System – Sidewall Images




Image Size 196MB

## Acquisition System - Sidewall

### Top Camera



Vertical axis to  
ajust camera  
position

Linear  
Camera

Two led bars  
illuminators

## Acquisition System – Sidewall Images



Image Size 196MB

## Acquisition System - Tread

### Left Tread Camera




### Right Tread Camera




## Acquisition System - Tread

- At this stage the tire stops for the 2 side cameras acquire the tread of the tire.




## Acquisition System – Sidewall Image Calibration Procedure

- The images acquired have artifacts that needs to be removed, namely:
  - Unbalanced white color
  - Image distortion
  - Width and Height are not proportional
  - Orientation of the Top Camera might be different from the Bottom Camera




- To correct the images we use 3 different calibrators patterns
  - 1 – Used to do the white balance of the cameras.
  - 2 – Used to remove horizontal (image plane) distortion.
  - 3 – Used to remove vertical (image plane) distortion and align Top and Bottom Cameras.

# Acquisition System – Sidewall Inspection Algorithm



# Acquisition System – Tread Inspection Algorithm



## ❑ The winner strategy

### ❑ Acquisition setup

- ❑ High resolution linear cameras vs Matrix cameras
- ❑ High definition linear illumination

### ❑ Calibration strategy

- ❑ Color balance
- ❑ Distortion removal

### ❑ Leading to simple algorithms



**ENERMETER**

*Seeing in first*



**CMMIDEV /2<sup>SM</sup>**  
Exp. 2018-06-12 / Appraisal #24559



**ESOVYM**

ENERMETER System Of VineYard  
Monitoring



## □ Remote Detection

items	Satellite	Aircraft – Manned	Aircraft – Unmanned
Image Resolution	Low resolution (1 - 40 m / pixel)	Spatial resolution – 50 cm	Spatial resolution – 5 cm
Weather condition	It depends on the weather condition	Meteorology (not operating) - Low clouds	Meteorology (not operating) - Rain and fog
Cost	high cost	Operating Cost - Average cost	Operating cost - Low cost
Coverage area	Ideal for large coverage areas	Use - Medium installments > 30 ha	Use - Small portions < 30 ha
others	Image data dependent of the satellite route	Attention must be paid to the influence of the thermal flow from the acquisition of IR image	- With the appearance of low cost drones some Unmanned Aircrafts are now used - Thermal flow from the acquisition of IR image



- Remote Detection – present limitations
  - information that is delivered to the vineyard manager is limited to the canopy, which can be confused with soil;
  - indicators obtained by aerial images may not reflect the true state of the vineyard, in situations of very dense or sparse density of leaf area



- Remote Detection – present limitations
  - indexes may suggest the existence of stress on the vine, but using only the aerial image is not possible to identify which type of stress; it is necessary to go to vineyards for further analysis
  - from currently used indicators it is difficult to infer other factors such as size of the vegetative hedge, leaf area, number and density of grapevines



- Remote Detection – present limitations
  - finally, another important factor is related to operation cost and logistics of current systems. These two aspects lead to collect aerial information mainly only on véraison stage, leaving outside the flowering and maturation stages



## Remote Detection

### ESOVYM – what we want

- Spatial resolution <2 cm**
- Image acquisition of all vegetative hedge**
- Cost of operation - operation during other jobs**
- Use - Portable system and without supervision by operator**
- Extract a new set of indicators, such as**
  - Leaf area index
  - Hedge size index vegetative
  - Leaf area ratio (m<sup>2</sup> / ha) for grape production (kg)



The overall goal of the project was the development of a mobile unit for acquisition and processing of vineyards images with high resolution and detail

In the validation process of the results, we obtained the cooperation of Sogrape. Which it gave access to their farms in Anadia; Barcelos and Douro




## Specific Goals

- During displacement, the unit performs simultaneously the acquisition of images (in the visible and infrared spectrum) of left and right trellis for processing, analysis and visualization.
- Acquisition of 100% of the target area of the vineyard and of entire vines' canopies, generating high resolution maps of the whole leaf surface without need for expertise in navigation or software.



## ❑ Technologies









□ Functionalities - After **automatic** processing and image analysis procedures

□ The system **creates geo-referenced maps** with traditional indicators, such as NDVI (Normalized Difference Vegetation Index)

□ **Besides these traditional** indicators a set of others can be obtained

□ The operator can



- multiresolution analysis and display
- Navigate through geo-referenced maps
  - Navigate through the panoramic images of the trellis
  - Navigate through the set of all images acquired – raw data



**ESOVYM**  
ENERMETER  
SYSTEM OF  
VINEYARD  
MONITORING



High level  
information  
(high degree of  
abstraction)



Intermediate level  
information  
(panoramic image)

More detailed information (lower degree of abstraction)



### Data acquisition Hardware



### Data production module

- Trajectory construction (GPS + IMU)
- Point Cloud generation (LIDAR)
- Image pre-processing (Camera)



### Post-processing module

- Point Cloud adjustment
- Panoramic generation



### Maps generation module

- Points of interest classification
- Maps generation and reports



- ESOVYM – actual indicators extracted
  - Photosynthetic Vigour Ratio - G/R;
  - Plant Pigment Ratio - G/B;
  - Plant Cell Density - IR/R;
  - Excessive Green Index -  $(2*G-R-B)$ ;
  - Normalized Difference Vegetation Index -  $(IR-R)/(IR+R)$ ;
- Leaf area index



**Photosynthetic Vigour Ratio index**




**Plant Pigment Ratio index**



**Leaf area index**








## ❑ Conclusions / General Features

- ❑ Robust and maintenance-free
- ❑ Flexible for different applications – using agricultural tractor
- ❑ Low operating cost – can be done at the same time of other operations
- ❑ Portable and without the need for operator supervision



CMMI DEV / 2<sup>SM</sup>  
Exp. 2018-06-12 / Appraisal #24559





# MICABCAD

Microcalcification Computer-Aided  
Detection

## □ Detection of microcalcifications in direct digital mammography

- Main Technical Objectives
  - Micro-calcification enhancement and detection;
  - Clusters identification and malignancy prediction








ENERMETER  
**MEDICAL IMAGING**



Centro de Computação Gráfica



Parque Industrial de Celeirós, 2<sup>a</sup> Fase  
Lugar de Gaião – Lotes 5/6  
4705-025 Aveleda, Braga – PORTUGAL  
T. (+351) 253 287 237  
[enermeter@enermeter.pt](mailto:enermeter@enermeter.pt)  
[www.enermeter.pt](http://www.enermeter.pt)



**CMMI DEV / 2<sup>SM</sup>**  
Exp. 2018-06-12 / Appraisal #24559

A ENERMETER preocupa-se com a sustentabilidade e proteção ambiental. Todos os suportes de comunicação, marketing e economato são impressos em papel fabricado com matéria-prima natural e renovável, 100% reciclável e produzido com tecnologias limpas.

